

Macro Twin Lite MT-24EX Compatibility Information 兼容資料																						
MR-14EX		Normal Shooting 正常拍攝															Wireless Shooting (as a Master unit) 無線拍攝 (作為主控單元單元)					
Camera 相機	Type 類型	Max. Sync Speed (sec.) 最高閃燈 同步速度 (秒)	Flash Metering System 閃燈測光系統			Manual Flash 手動閃光	Stroboscopic Flash 頻閃	High-speed Sync 高速同步	FE Lock 閃燈 曝光鎖	Flash Exposure Compensation 閃燈曝光補償		Flash Exposure Bracketing 閃燈包圍曝光	Modeling Flash 造型閃光	Second- curtain Sync 後簾同步	Auto Zoom for Sensor Size 配合影像感應 器自動變焦	Color Temperature Information Transmission 色溫資料傳送	Manual Focusing Lamp 手動 對焦指示燈	Optical Pulse Transmission 光脈衝傳送				
			E-TTL II	E-TTL	TTL					Flash 閃光燈	Camera 相機							E-TTL II/E-TTL Autoflash E-TTL II/E-TTL 自動閃光	Manual flash 手動閃光	High-speed Sync 高速同步	Max No of Firing Group 最多支援 燈組	
DIGITAL CAMERA / 數碼相機	EOS 100D	A	1/200	0	x	x	0	Not Supported 不支援	0	0	0	0	0	0	Not Supported 不支援	Not Supported 不支援	0	0	0	0	1 (Group C)	
	EOS 700D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 6D	A	1/180	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS M	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 650D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS-1D X	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 5D Mark III	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 1100D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 600D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 60D/60Da	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 550D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS-1D Mark IV	A	1/300	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 7D	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 500D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 5D Mark II	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 50D	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 1000D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 450D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 40D	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS-1Ds Mark III	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS-1D Mark III	A	1/300	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 400D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 30D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 5D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS-1D Mark II N	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 350D	A	1/200	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS-1Ds Mark II	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 20D/20Da	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS-1D Mark II	A	1/250	0	x	x	0		0	0	0	0	0	0			0	0	0	0	1 (Group C)	
	EOS 300D	A	1/200	x	0	x	0		0	0	0	x	0	0	0		0	0	0	1 (Group C)		
	EOS 10D	A	1/250	x	0	x	0		0	0	0	0	0	0	0		0	0	0	1 (Group C)		
	EOS-1Ds	A	1/250	x	0	x	0		0	0	0	0	0	0	0		0	0	0	1 (Group C)		
	EOS D60	A	1/200	x	0	x	0		0	0	0	0	0	0	0		0	0	0	1 (Group C)		
	EOS-1D	A	1/500	x	0	x	0		0	0	0	0	0	0	0		0	0	0	1 (Group C)		
	EOS D30	A	1/200	x	0	x	0		0	0	0	0	0	0	0		0	0	0	1 (Group C)		
FILM CAMERA / 菲林相機	EOS 300X	A	1/125	0	x	x	0		0	0	0	x	0	0	0	N/A 不適用	N/A 不適用	0	0	0	0	1 (Group C)
	EOS 30V / 33V	A	1/125	0	x	0 ¹	0		0	0	0	0	0	0	0			0	0	0	1 (Group C)	
	EOS 3000V	A	1/90	x	0	x	0		0	0	0	x	0	0 ²	0			0	0	0	1 (Group C)	
	EOS 300V	A	1/90	x	0	0 ¹	0		0	0	0	x	0	0	0			0	0	0	1 (Group C)	
	EOS 66	A	1/90	x	0	0 ¹	0		0	0	0	x	0	x	0			0 ³	0	0	1 (Group C)	
	EOS 30/33	A	1/125	x	0	0 ¹	0		0	0	0	0	0	0	0			0	0	0	1 (Group C)	
	EOS-1V	A	1/250	x	0	0 ¹	0		0	0	0	0	0	0	0			0	0	0	1 (Group C)	
	EOS 300	A	1/90	x	0	0 ¹	0		0	0	0	x	0	0 ²	0			0 ³	0	0	1 (Group C)	
	EOS 88	B	1/90	x	x	0	0		x	x	0	x	0	x	0			x	0	x	1 (Group C)	
	EOS-3	A	1/200	x	0	0 ¹	0		0	0	0	0	0	0	0			0	0	0	1 (Group C)	
	EOS IX 7	A	1/125	x	0	0 ¹	0		0	0	0	x	0	0 ²	0			0 ³	0	0	1 (Group C)	
	EOS IX	A	1/200	x	0	0 ¹	0		0	0	0	0	0	0 ²	0			0 ³	0	0	1 (Group C)	
	EOS 500N	A	1/90	x	0	0 ¹	0		0	0	0	x	0	0 ²	0			0 ³	0	0	1 (Group C)	
	EOS 50E	A	1/125	x	0	0 ¹	0		0	0	0	0	0	0 ²	0			0 ³	0	0	1 (Group C)	
	EOS-1N RS	B	1/250	x	x	0	0		x	x	0	0	x	0	0			x	0	x	1 (Group C)	
	EOS 888	B	1/90	x	x	0	0		x	x	0	x	0	x	0			x	0	x	1 (Group C)	
	EOS-1N	B	1/250	x	x	0	0		x	x	0	0	x	0	0			x	0	x	1 (Group C)	
	EOS 500	B	1/90	x	x	0	0		x	x	0	x	0	x	0			x	0	x	1 (Group C)	
	EOS 5	B	1/200	x	x	0	0		x	x	0	0	x	0	0			x	0	x	1 (Group C)	
	EOS 1000FN	B	1/90	x	x	0	0		x	x	0	x	0	x	0			x	0	x	1 (Group C)	
	EOS 100	B	1/125	x	x	0	0		x	x	0	x	0	0	0			x	0	x	1 (Group C)	
	EOS 1000F QD	B	1/90	x	x	0	0		x	x	0	x	0	x	0			x	0	x	1 (Group C)	
	EOS 700	B	1/125	x	x	0	0		x	x	0 ⁴	x	0 ⁴	0 ⁴	0			x	0 ⁵	x	1 (Group C)	
	EOS 10	B	1/125	x	x	0	0		x	x	0	x	0	0	0			x	0	x	1 (Group C)	
	EOS RT	B	1/125	x	x	0	0		x	x	0	x	0	0	0			x	0	x	1 (Group C)	
	EOS-1	B	1/250	x	x	0	0		x	x	0	x	0	x	0			x	0	x	1 (Group C)	
	EOS 630	B	1/125	x	x	0	0		x	x	0	x	0	0	0			x	0	x	1 (Group C)	
	EOS 850	B	1/125	x	x	0	0		x	x	x	x	x	x	x			x	0	x	1 (Group C)	
	EOS 750 QD	B	1/125	x	x	0	0		x	x	x	x	x	x	x			x	0	x	1 (Group C)	
	EOS 620	B	1/250	x	x	0	0		x	x	x	x	x	x	0			x	0	x	1 (Group C)	
	EOS 650	B	1/125	x	x	0	0		x	x	x	x	x	x	0			x	0	x	1 (Group C)	

*1: Enabled by Speedlite's custom function / 透過自訂功能啓動
*2: If [C, Fn-02] (Modeling flash) is set to [1] (Enabled: Test firing button) or [2] (Enabled with both button), modeling flash is possible / 須設定自訂功能C.Fn-02 (造型閃光) 為 [1: 啓動 (測試閃燈按鈕)] 或 [2: 啓動 (兩個按鈕皆可)]才可使用造型閃光
*3: Single slave group control / 只支援一組從屬燈組控制
*4: For EOS 700, enabled with shutter speed-priority AE / 使用EOS 700相機，設定為快門先決自動曝光後啓動
*5: For EOS 700, the aperture will be fixed at f/5.6 / 使用EOS 700相機，光圈值會固定為f/5.6